


## Unpacking

Before you begin using the device, please check the version you got and ensure that the following items are included in the shipped box:

### Mainframe Accessories(Please find in device box):



### Wall-mounting Accessories(Please find in On-wall Installation Kit box):



### Flush-mounting Accessories(Please find in In-wall Installation Kit box):



## Product Overview




## Installation Environment


Indoor and outdoor installation are supported.

If installing the device outdoors, please don't place device under direct sunlight, it will bring a bad effect or be broken with the high temperature.


If installing the device indoors, please keep device at least 2 meters away from light, and at least 3 meters away from window and door .




Backlight




Direct sunlight



Direct sun through window



Indirect sunlight through window



Close to light

Attention:


Biometric recognition product may not be considered 100% to fit in any identification application.

For higher security purpose or scenario, please set up access authentication combination.


## Installation

### Step 1: Box Installation


#### 1. Wall-Mounting




Hold the back of the wall-mounting box close to the wall, and make sure that the opening in the green area on the left is the wire hole position for the wall and adjust it to a horizontal position. Mark the six holes of the wall-mounting box on the wall.



Use a drill with 5 mm diameter bit to make holes in the marked positions.




Insert the screw fixing seats into the holes.



Fix the wall-mounting box with six ST4x20 screws.


#### 2. Flush-Mounting

##### 2.1 Normal Installation




Cut a rectangular hole on the wall of the diameter of 358x319 mm and depth of 58 mm that can accommodate and through out all necessary cables.


Note: The size of the hole should be a little larger than recommended value.




Insert the flush-mounting box into the hole and make sure the cables of the device can route through the suitable cable holes. Then mark the six holes of the flush-mounting box on the wall.




Use a drill with 5 mm diameter bit to make holes in the marked positions.



Insert the screw fixing seats into the holes you drilled before.




Place the flush-mounting box into the rectangular hole and route all cables through the cable holes. Fix the embedded box with six ST4x20 screws.




Flush-mounting box is installed.


## 2.2 Or you can choose another simple method without fixing ST4x20 screws



Cut a rectangular hole on the wall of the diameter of 358x319 mm and depth of 58 mm that can accommodate and through out all necessary cables.  
Note: The size of the hole should be a little larger than recommended value.




Use cement or non-corrosive structural adhesives to fill the gap between the wall and flush-mounting box. Wait the adhesive material desiccation, go to the next step.




Flush-mounting box is installed.


## STEP 2: Cable locking plate and terminals Installation




Connect the terminal blocks to the cables as needed. 2-PIN terminal block can only be used for power Input port. For details, refer to "Device Wiring".



Make cables of the installed terminal blocks go through the hole of the cable locking plate, connecting to the corresponding interfaces of the main board.




Fasten the cable locking plate with eight M3x4 screws.




When disassembling, insert the end of the crowbar without the thin steel sheet between the device and the terminal blocks, and then pry up the terminal blocks in the direction of the arrow in the figure.


## STEP 3: Device Mounting




Insert the device into the wall-mounting box/flush-mounting box, pull the device downward to ensure the six pegs on the back of which hooked to the hanging holes of the box.  
Then use the torx wrench to tighten the device with two M3x8 screws.



Place the card reader cover into the groove of card reader area (Please note that the small round hole on which must be in the upper left corner), and press around to fix it.




Finished.




When disassembling, please use the Removal tool, insert into the small round hole in the upper left corner of the card reader cover and pull it out.

## Device Wiring



## Application Scenario



## Configuration

- 1.IP Address Checking: Press 9999 in dialing interface, then input 3888 to enter the system interface. Click Info to check the IP address. X916 uses DHCP by default.
- 2.Account Registration: On web UI, go to the path: **Account -> Basic** page to register account and fill in the account information. ( *Please refer to user manual for more information* )
- 3.DTMF Code Configuration: On web UI, go to the path: **Intercom -> Relay -> Relay ID/ DTMF** choose the DTMF code number in corresponding area.

## Operation

### Make a call:

Input the room number, press Dial key to make a call.

### Unlock by DTMF:

During the call, press the corresponding DTMF code from answer unit to unlock X916 remotely.

### Unlock by Private Key:

In the PIN/PASSWORD interface, enter the password to open the door.

### Unlock by RF Card:

Place the predefined RF Card in the RF reader area to open the door.



### Notice Information

Information contained in this document is believed to be accurate and reliable at the time of printing. This document is subject to change without notice, any update to this document can be viewed on Akuvox's website: <http://www.akuvox.com> © Copyright 2019 Akuvox Ltd. All rights reserved.

